



F-5 External View

F-5 Flexible Coupling Additional Installation Notes (Also see standard coupling instruction sheet)

- Drill or bore a 1/4" diameter hole straight into the center of the larger machinery shaft.
- Insert the coupling into that hole.
- Tighten the hub expansion screw inside of the coupling to expand the hub; this secures the coupling to the machinery shaft.
- Select the insert corresponding to the encoder shaft diameter (1/4", 5/16" or 3/8") and insert it into the coupling.
- Insert the encoder shaft into the coupling
- Tighten the collar of the coupling (this will clamp the encoder shaft)

F-6 Coupling: Same as F-5 except expandable hub (and required shaft bore) is 3/8" instead of 1/4"

F-5 (& F-6) Coupling Sketch & Installation Notes	
	FSI Technologies Inc. 668 Western Ave. Lombard, Illinois 60148
	Sketch #: SDOC-043-017